Thermo-Perch™ & Sand Thermo-Perch™

Care & Instructions



Thank you for purchasing K&H Manufacturing's Thermo-Perch™ or Sand Thermo-Perch™.

WARNING: This is an electrical product. Read all directions and precautions carefully before operating. Failure to properly follow all directions and instructions may lead to electrical shock or fire which could cause serious bodily injury.

USE INSTRUCTIONS

Read all instructions carefully. This is an electrical product, pay special care to IMPORTANT SAFEGUARDS.

- Remove all contents from the package. Plan on placing the Thermo-PerchTM in the upper third of the cage, adjacent to the highest perch, as most birds select the highest spot for sleep and safety.
- Unscrew the retaining flange from the perch.
 Run the perch cord through the bars of the cage. While holding the perch in place, slide the retaining flange up the cord and screw the retaining flange onto the threads. Hand-tighten until the Thermo-Perch™ is firmly in place.
- Plug the AC adaptor into an outlet, and plug the adaptor cord into the perch. It can take up to an hour for the unit to reach its consistent temperature.
- It may take time for the bird to use the perch consistently, as some birds are wary of any new object in their cage. Be patient and leave the perch alone. It may even take a week or more for your bird to get used to having a new perch in its cage.
- Exotic birds have a body temperature that ranges between 104-106°F. The Thermo-Perch™ is thermostatically controlled to help them safely regulate their body temperature. Your bird will position itself on the perch based on the amount of warmth it desires. THE Thermo-Perch™ IS NOT INTENDED TO BE THE ONLY PERCH IN THE CAGE. Your bird will choose when it needs the warmth, and there should always be at least one other non-heated perch to use.

When used correctly, your Thermo-Perch™ should provide years of hassle free warmth & comfort for your birds.

IMPORTANT SAFEGUARDS

For household Use Only*

*The heated pad is an electrical device and must only be operated inside an enclosure such as a porch, shed, barn, dog house, or cat house.

When using electrical appliances, basic safety precautions should always be followed including the following:

- Read all instructions.
- The perch is made of a chew-resistant plastic, and the cord is metal wrapped to prevent chewing. Please take care not to let the cord hang near or into the cage as a determined parrot may still cause some cord damage. The cord may also be of interest to the bird it if is let out of the cage to roam. K&H Manufacturing is not responsible for damaged cords.
- The perch is made of a chew-resistant plastic, and the cord is metal wrapped to prevent chewing. Please take care not to let the cord hang near or into the cage as a determined parrot may still cause some cord damage. The cord may also be of interest to the bird it if is let out of the cage to roam. K&H Manufacturing is not responsible for damaged cords.
- The Thermo-Perch™ is a low-voltage heating unit using a UL Listed AC adapter and cannot shock you bird.

Care Instructions:

The Thermo-Perch™ may be cleaned with a damp cloth or paper towel. DO NOT IMMERSE IN WATER. If disinfecting is required, lightly mist the Thermo-Perch with disinfecting solution and wipe dry. Take care not to mist the area where the cord enters the perch.



K&H Limited One Year Warranty

Our warranty is as follows: K&H Manufacturing warrants to the original consumer, that this product will be free of defects and workmanship for a period of one year from the date of purchase. The manufacturer's liability hereunder is limited to replacement of the product. This warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material or workmanship.

To exercise your warranty: If, during the warranty period, your product malfunctions, return it to the place of purchase with your original purchase receipt. If this cannot be done, return the product, postage prepaid, to K&H Manufacturing, with dated proof of purchase or original date receipt. A return authorization number, obtained by calling (719) 591-6950 must accompany all returns to manufacturer. Please include a note explaining the problem when returning the product.