Perfect Bucket Heater™

Care & Instructions

Made in China
K&H Manufacturing, LLC
Colorado Springs, CO
www.khmfg.com | (877) 738-5188

Thank you for purchasing the Perfect Bucket Heater™ by K&H Manufacturing. The Perfect Bucket Heater™ will keep buckets up to 16 gallons ice-free using only 80 watts! Safe for metal or plastic buckets.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

- Have a qualified electrician install a properly grounded outlet, acceptable for outdoor use and protected from snow and rain immediately adjacent to the location where the heater will be used. If your outlet is not a GFCI outlet or if you are unsure, have a qualified electrician inspect and install one if needed.
- Route supply cord and locate the heater so as to be protected from damage by livestock.
- Do not use extension cords.
- Inspect cord before using. If the cord is damaged do not use.
- Unplug heater at receptacle outlet when not in use or before removal from bucket.
- Store bucket heater indoors after the winter season.



WARNING:

THE PERFECT BUCKET HEATER™ MUST
BE SUBMERGED UNDER WATER AT ALL TIMES
while it is in use!

STORING YOUR PERFECT BUCKET HEATER™:

After the winter season, always unplug your Perfect Bucket HeaterTM and remove it from the bucket. Make sure your bucket heater is dry and properly cleaned before storing it away in a dry, safe place, out of direct sunlight and away from work areas where it may become damaged.

For re-installation, always carefully inspect your Perfect Bucket Heater™ before plugging it in. Inspect the cord, the housing and the plug for any damage. If you see any cracking of the cord or other damage, DO NOT USE DEVICE!

K&H Limited Two Year Warranty

Our warranty is as follows: K&H Manufacturing warrants to the original consumer, that this product will be free of defects and workmanship for a period of two years from the date of purchase. The manufacturer's liability hereunder is limited to replacement of the product. This warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material or workmanship.

To exercise your warranty: If, during the warranty period, your product malfunctions, return it to the place of purchase with your original purchase receipt. If this cannot be done, return the product, postage prepaid, to K&H Manufacturing, with dated proof of purchase or original date receipt. A return authorization number, obtained by calling (719) 591-6950 must accompany all returns to manufacturer. Please include a note explaining the problem when returning the product.

Perfect Bucket Heater™

Care & Instructions

Made in China K&H Manufacturing, LLC Colorado Springs, CO www.khmfg.com | (877) 738-5188



Thank you for purchasing the Perfect Bucket Heater™ by K&H Manufacturing. The Perfect Bucket Heater™ will keep buckets up to 16 gallons ice-free using only 80 watts! Safe for metal or plastic buckets.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

- Have a qualified electrician install a properly grounded outlet, acceptable for outdoor use and protected from snow and rain immediately adjacent to the location where the heater will be used. If your outlet is not a GFCI outlet or if you are unsure, have a qualified electrician inspect and install one if needed.
- Route supply cord and locate the heater so as to be protected from damage by livestock.
- Do not use extension cords.
- Inspect cord before using. If the cord is damaged do not use.
- Unplug heater at receptacle outlet when not in use or before removal from bucket.
- Store bucket heater indoors after the winter season.



WARNING:

THE PERFECT BUCKET HEATER™ MUST BE SUBMERGED UNDER WATER AT ALL TIMES while it is in use!

STORING YOUR PERFECT BUCKET HEATER™:

After the winter season, always unplug your Perfect Bucket HeaterTM and remove it from the bucket. Make sure your bucket heater is dry and properly cleaned before storing it away in a dry, safe place, out of direct sunlight and away from work areas where it may become damaged.

For re-installation, always carefully inspect your Perfect Bucket Heater™ before plugging it in. Inspect the cord, the housing and the plug for any damage. If you see any cracking of the cord or other damage, DO NOT USE DEVICE!

K&H Limited Two Year Warranty

Our warranty is as follows: K&H Manufacturing warrants to the original consumer, that this product will be free of defects and workmanship for a period of two years from the date of purchase. The manufacturer's liability hereunder is limited to replacement of the product. This warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material or workmanship.

To exercise your warranty: If, during the warranty period, your product malfunctions, return it to the place of purchase with your original purchase receipt. If this cannot be done, return the product, postage prepaid, to K&H Manufacturing, with dated proof of purchase or original date receipt. A return authorization number, obtained by calling (719) 591-6950 must accompany all returns to manufacturer. Please include a note explaining the problem when returning the product.