



SELF-WARMING KITTY SILL

K&H PET PRODUCTS
CENTRAL GARDEN & PET
COLORADO SPRINGS, CO
www.khpet.com • 1-877-738-5188

PATENTED - U.S. Patent #9,924,697
K&H Pet Products with design
is a registered trademark of
K&H Manufacturing, LLC.
©2025 K&H Manufacturing, LLC.



BEFORE ASSEMBLY check that you
have received all of the parts needed:



ASSEMBLY:

- 1 On a flat surface, lay out the **COVER**, **FRAME SIDES** and **STABILITY RODS** right side down. Open up the hook + loop closures on all sides of the **COVER**.
- 2 Attach the **STABILITY RODS** into the plastic joints of each **FRAME SIDE** to make the **CONNECTED FRAME**. Be sure the connection points are firmly joined.
- 3 Fold the hook + loop closures of the **COVER** over all sides of the **CONNECTED FRAME**. Attach the **SUCTION CUPS** to the back corner bars of the **CONNECTED FRAME**. This may require some effort, they are meant to be very firmly attached.

INSTALLATION:

IMPORTANT: Thoroughly clean your **WINDOW** and **SUCTION CUPS** before you install the product for maximum hold!

- 1
 - 2
 - 3
 - 4
 - 5
- Line up the top **SUPPORT STRAP SUCTION CUPS** with the **FRAME SUCTION CUPS** below them. Gently push each of the top **SUPPORT STRAP SUCTION CUPS** onto the window. Be sure that each **SUPPORT STRAP** has a similar tension.
- Check that the **FRAME** is level from the front and the side. Readjust as needed.
- Gently push one side of the **FRAME SUCTION CUPS** onto the window. Level the **FRAME** from the front and gently attach the second **FRAME SUCTION CUP**.
- Push the excess air out of each **SUCTION CUP** with your finger for a firm hold.
- TO OPERATE WINDOW COVERINGS:**
- Flip the **FRAME** of the lounge upwards so that it is flat against the window pane.
- Pull back the top corners of the hook + loop on the **COVER**. Secure each **SUPPORT STRAP** in the hook + loop and press down to adhere.
- Window coverings can now be closed in front of the Kitty Sill.

06-01-25

CAUTION: Like most suction cups, debris, temperature changes, sunshine and excessive use can weaken the holding power. Remove suction cups once a month to clean both window and cup then reinstall for optimal strength.

CARE OPTIONS:

1. Machine wash cover on gentle, line dry.
2. Wipe frame with damp cloth.

To initiate a warranty claim during the warranty period, please follow the steps below:
Call our customer service team at **877-738-5188** or email us at questions@khmfg.com.
Please include the following details when contacting us:

- A clear description of the defect.
- Pictures of the defect (this will help us assess the issue more efficiently).
- Proof of purchase (receipt or order confirmation) to verify the product's eligibility for warranty coverage.

Upon receiving your claim, we will promptly review the information provided and notify you of the next steps in the replacement process.

We are committed to ensuring your satisfaction and will assist you in resolving any warranty concerns as quickly as possible.

THANKS!