

# Kitty Sill - Double Stack EZ Window Mount™

## Care & Instructions

Made in China  
K&H Manufacturing, LLC  
Colorado Springs, CO  
www.khmf.com | (877) 738-5188  
patent pending



**Thank you for purchasing K&H Manufacturing's Kitty Sill - Double Stack EZ Window Mount™.**  
When used correctly, your EZ Window Mount™ should provide years of hassle comfort and window viewing for your cat.

### INSTRUCTIONS:

Please read all instructions before installation.

- Using glass cleaner, thoroughly clean and dry the window that will accommodate the EZ Window Mount™.
- Clean each suction cup to ensure proper adhesion to window.
- Holding the bottom (no hole) platform with the suction cups already attached, gently push one suction cup against the window. See **Figure 1**.
- Level the platform and gently push the second suction cup of that floor against the window.
- Push remaining air out of suction cups to ensure a proper adhesion.
- Lift top platform to the desired level, suspending the bottom platform with the support straps. Adhere the platform suction cups as in steps 3, 4 and 5. See **Figure 2**.
- Align each support strap and adhere the Push'n'Turn suction cups to the window taking care to keep similar tension on each strap, see **Figures 3 & 4**. (To use *Push'n'Turn suction cups* see further instructions below.)
- Step back and check to be sure platforms are level. If not, disconnect and adjust one suction cup at a time to level your new Double Stack EZ Window Mount™ kitty sill.

### Push'n'Turn:

This product features our revolutionary, Push'n'Turns suction cups.

Turn the tensioning knob **counter clockwise** to loosen the cup mechanism (**Figures 3 & 4**). Loosen it until it almost comes off the threaded post. Locate the proper spot on the window, seat the suction cup against window and firmly push the end of the knob to remove air from cup. Slowly turn the tensioning knob **clockwise** until tight.



FIGURE 1




FIGURE 2



FIGURE 3



FIGURE 4

### To operate blinds, curtains & windows:

To operate blinds, curtains and window coverings with Kitty Sill attached, simply flip your new Kitty Sill up against window. Run straps back through the holes in the corners to support the platform in the upright position. Blinds can now operate normally.

### Care Instructions:

Remove covers. Machine wash & line dry. Wipe frame with a damp cloth.

**Caution:** As with any suction cup, debris, temperature changes, sunshine and excessive use can weaken the holding power. We recommend removing the suction cups at least once per month to clean the window area, clean the suction cups and then re-install them for optimal strength.

### K&H Limited One Year Warranty

**Our warranty is as follows:** K&H Manufacturing warrants to the original consumer, that this product will be free of defects and workmanship for a period of one year from the date of purchase. The manufacturer's liability hereunder is limited to replacement of the product. This warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material or workmanship.

**To exercise your warranty:** If, during the warranty period, your product malfunctions, return it to the place of purchase with your **original purchase receipt**. If this cannot be done, return the product, postage prepaid, to K&H Manufacturing, with **dated proof of purchase or original date receipt**. A return authorization number, obtained by calling (719) 591-6950 must accompany all returns to manufacturer. Please include a note explaining the problem when returning the product.