

K&H Thermo-Chicken Perch™

Care & Instructions

Made in China
K&H Manufacturing, LLC
Colorado Springs, CO
www.khmf.com | (719) 591-6950



Thank you for purchasing K&H Manufacturing's Thermo-Chicken Perch™. When used correctly, the gentle warmth of the Thermo-Chicken Perch™ will aid in the retention of body heat by warming a bird's entire body utilizing its own circulation system. The K&H Thermo-Chicken Perch™ also prevents lost toes due to frostbite! A warm perch = happy and healthy birds!

WARNING: This is an electrical product. Read all directions and precautions carefully before operating. Failure to properly follow all directions and instructions may lead to electrical shock or fire which could cause serious bodily injury.

PLEASE READ:

Smart technology has been incorporated into your new K&H THERMO-CHICKEN PERCH™. The dual thermostats accomplish several energy saving goals:

1. The thermostat built into the cord constantly monitors air temperature, turning the perch on **ONLY** when temperatures fall to the near freezing point and below.
2. A thermostat inside the perch itself maintains optimal and safe temperatures for your prized poultry.

Remember, your perch **WILL NOT OPERATE WHEN AMBIENT AIR TEMPERATURES ARE ABOVE 35 DEGREES.**

In extreme cold, your perch may feel cool to the touch. This is because extremely cold air will "wick" the heat off the steel surface faster than it can accumulate. Be assured, the internal airspace of the perch is still a toasty 99 degrees or so.

This warmth will wick through into the bird's feet when roosting. You can test this by wrapping a cloth around a portion of the perch in cold weather. After a few minutes, feel under the cloth to experience the warmth of the perch. Your birds will love it!

ASSEMBLY:

- 1 After unpacking the contents, simply seat the 4 legs into the joints at the ends of the perch, making sure they are fully seated into the holes.
- 2 Locate the desired location for your roosting birds. Simply plug it in!

PLEASE NOTE:

Your perch **will not operate in warmer weather.** Near freezing conditions must exist for your perch to automatically turn on.

Cleaning:

Your K&H THERMO-CHICKEN PERCH™ may be wiped down with a soap solution and a damp cloth. Thoroughly dry before using.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

- **Read all instructions.**
- To protect against electrical hazards, **DO NOT** immerse cord, plug, or appliance in water or other liquid.
- **Close supervision is necessary** when used by or near children.
- **ALWAYS** unplug from outlet when not in use.
- **DO NOT** operate any electrical appliance with a damaged cord or plug, or if the appliance malfunctions or has been damaged in any way. **RETURN** all malfunctioning appliances to the factory for examination.
- **DO NOT** use appliance for anything other than its intended use.
- **DO NOT PUNCTURE HOUSING FOR ANY REASON.**
- For use with 110-120 volt AC **ONLY**.
- When used outside your home, this unit must be plugged into a properly grounded electrical outlet rated for outdoor use. If you do not have a properly grounded outlet, contact a certified electrician to have one installed.
- Always make sure the cord exits your pet's enclosure. Keep cord out of shelter.

K&H Limited One Year Warranty

Our warranty is as follows: K&H Manufacturing warrants to the original consumer, that this product will be free of defects and workmanship for a period of one year from the date of purchase. The manufacturer's liability hereunder is limited to replacement of the product. This warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material or workmanship.

To exercise your warranty: If, during the warranty period, your product malfunctions, return it to the place of purchase with your **original purchase receipt**. If this cannot be done, return the product, postage prepaid, to K&H Manufacturing, with **dated proof of purchase or original date receipt**. A return authorization number, obtained by calling (719) 591-6950 must accompany all returns to manufacturer. Please include a note explaining the problem when returning the product.